HV8030C, HV8030W Installation Instructions



PRODUCT SPECIFICATIONS		DIMENSIONS	IMAGE
Model No.	HV8030C, HV8030W		
Name	Aurora		
Material	Plaster & Aluminium		
Colour	White		
IP Rating	IP20		
Input Voltage	240V		
Lamp Base	E14		
Lamp Wattage	3w		
CRI:	>80		
Wiring	Parallel		
Dimmable	No		
Warranty	2 Years Replacement		

Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- Do not exceed maximum wattage restrictions for globes: 240V GU10 = 35w / 12V MR16 = 20w
- Modification of this product will void any warranty.
- Havit Lighting does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- When installing low voltage fittings, Voltage to fitting must be within +or- 5% of voltage required, if not within this allowance warranty will be voided.
- Aluminium and 304SS fittings must not be installed within 2km of any salt water environments.
- When installing copper fittings, gloves must be worn to avoid any oils transferring to fitting.
 All 316 stainless steel fittings must have regular cleaning maintenance to avoid any tea staining from forming on fitting.
- (Warranty does not cover Tea Staining)
- All o-rings and seals must be in place correctly to maintain warranty.

Steps for Installation:

- 1. Make sure that the electrical circuit is free of voltage (master switch off).
- 2. Remove the fitting from backing plate by undoing the screws.
- 3. Install backing plate securely.
- 4. Connect the cable using wire with earth. Connect earth first, then live and neutral wires.
- 5. Affix the face of the fitting to the backing plate, making sure screws are tight.
- 6. Insert globe provided.
- 7. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.
- 8. Fitting can be easily painted to match decor.

Steps for Changing Globe:

- 1. Ensure light is switched off.
- 2. Remove the globe from the lampholder by twisting anti-clockwise.
- 3. Insert the new globe by holding at the base and twisting clockwise until firmly in place.
- 4. Make sure not to exceed max wattage, see product label for correct info.

Must be Installed by a Licensed Electrician

For More Information Contact Havit Lighting

143 Beauchamp Road Matraville NSW 2036 Australia Tel: 02 9381 8300 Fax: 02 9666 8881 Email: sales@havit.com.au Web: www.havit.com.au